

Steering wheel control interface installation kit for:


JEEP

Model: Renegade with VP2/VP2 NAV original RADIO;

Year: 2014>

Kit content: SWC interface
wiring harness
FM antenna adapter
DAB antenna adapter


Customer code:



INSTALLATION MANUAL

All installation work must be performed by a qualified professional installer only.
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.
10/2018 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.

All installation work must be performed by a qualified professional installer only.
The manufacturer / dealer is not liable for any kind of incidental or indirect damages.
10/2018 ALL RIGHTS RESERVED. Technical changes possible. No liability for misprints.



ATTENTION!

In order to prevent ESD damage, the WHEEL REMOTE JACK must be connected before plugging in the connectors on car side.

Connect cables to as follow:

- 1- to RADIO CONNECTOR
- 2- to CAR ANTENNA CONNECTOR
- 3- to CAR ANTENNA CONNECTOR (with iLX-702D, X802D-U, INE-W710D, iLX-F903D Radio)
- 4- to CAMERA IN
- 5- to AUX IN
- 6- Red wire UNDERKEY - available for external accessories MAX 500 mA
- 7- Yellow wire PERMANENT - available for external accessories
- 8- Black wire GND - available for external accessories
- 9- AUT ANTENNA SIGNAL
- 10- to CAMERA CONTROL
- 11- to CAR CONNECTOR
- 12- to RADIO ANTENNA CONNECTOR
- 13- to RADIO ANTENNA CONNECTOR (with iLX-702D, X802D-U, INE-W710D, iLX-F903D Radio)
- 14 - to the point n°9 (AUT ANTENNA SIGNAL)

NOTE: 15- Connect to point n°3 only if original RVC installed

NOTE: 16- Find near the steering wheel the area where air grille is placed (highlighted in the picture).

We suggest to place the buzzer behind this area for a better sound diffusion.

BUZZER CABLE




16



DASHBOARD

copy for the vehicle owner



The steering wheel buttons perform the following functions (if supported by the radio).

1- Source

2- Seek down

3- Seek up

4- Accept incoming call

5- Voice

6- Reject incoming call

7- Volume up

8- Volume down

9- Mute

If your vehicle has the configuration shown in the picture, the buttons can carry out the functions listed below:




- 1 Left => decrease Volume
- 1 Right => increase Volume
- 1 Press => toggle ignition
- 2 Press => mute
- 3 Press => toggle ignition
- 4 Left => seek -
- 4 Right => seek +
- 4 Press => toggle ignition

The available settings are (if the related optional is equipped by the car):

- Date & Time change
- Language change
- Follow me settings
- delayed reverse
- delayed reverse temporization
- camera guide lines visualization
- measure unit change
- temperature unit change
- pressure unit change
- ambient light intensity change
- courtesy lights setting
- cornering light setting
- light management at shutdown
- automatic high beam
- doors automatic closing setting
- passive entry setting
- door unlock selection
- automatic parking brake management
- anticollision warning setting
- parking sensor setting
- radio mute on parksensor setting
- lane assist settings
- lane assist strength
- blind spot warning management
- side sense management
- rain sensor settings

NOTE: Access the interface setting menu as shown in the pictures.



AUTO HVAC (Heat Ventilation Air conditioning and Cooling) ONLY

MAX AC: this function is not carried out by the vehicle buttons.

- The user must set the desired function MAX AC manually, by using the wheel and the buttons on the vehicle;

DUAL : this function is not carried out by the vehicle buttons.

- The user must press the OFF button twice to use the sync command;

Alpine H/U displays AC profile. This information can not be changed.

- Middle is displayed. Choices are: Low, Middle, High.

NOTE

Jeep Renegade parking sensors can be displayed in the dashboard display.

Parking Distance Control is active and emits sounds only if the vehicle is moving.