

# TRUCK-G500C

## Installation Manual



**Trucking Software for**  
**INE-W920R / INE-W925R / INE-W928R / INE-W977BT**

English  
March 2018, Version 1.0

## Installation instructions for INE-W920R / INE-W925R / INE-W928R and INE-W977BT:


- 1) Power the unit on. Select Navigation function and operate the unit until the display shows the map screen.
- 2) INE-W920R / INE-W925R: Insert the Micro SD card into the card slot below the detachable face plate.  
INE-W928R / INE-W977BT: Insert the Micro SD card adapter including the Micro SD card into the SD card slot located below the display.
- 3) A small software program will start automatically in the background, which takes less than one minute. Wait until the map screen is shown on the display.  
Caution: Do not power off the unit and do not switch off ACC.
- 4) Please note: The SD card has to remain inside the unit.

### How to adjust truck specific settings in the Navigation Software:

- 1) Press hard key "Navigation" and touch the "Settings" symbol from the Navigation Main Menu.  
(Example: INE-W920R)



- 2) Touch "Route Settings", and then touch "Vehicle".



- 3) Scroll down and select "Default Lorry".





- 4) Touch the “Settings” symbol in the “Default Lorry” selection bar to access the settings menus for the trucking feature allowing you to customize and adjust values applicable to your vehicle.



## How to buy newer map update:

- 1) Purchasing map update requires the download, installation and use of the NaviExtras Toolbox.
- 2) Remove the (Micro) Sd-card by entering the Main menu, selecting Settings, then select Update and press “Go!”.



Wait until the display shows “DB updatre tool – SD card can be removed for DB update...”!

- 3) To purchase new map update, insert the (Micro) SD-card into your PC. Then open the NaviExtras Toolbox on your PC. The (Micro) SD-card will be detected as your Alpine unit on the Toolbox.
- 4) After purchasing and download of the new map update, reinsert the (Micro) SD-card into your Alpine unit and wait until map screen is shown.